



## Thumb Screw for ASFA L and S worm-drive clamps

---

Worm-drive clamps can be fitted relatively tightly, easily and quickly using this Thumb Screw, without the need for tools. Once the clamp has been tightened, the thumb screw can be removed. Manufactured in durable red plastic.

Application Ø	Width Screw (mm)	Part n°	Box Quantity (MOQ)	Outer Packing
All Ø available ASFA L and S	7	0217046-1	100	1.000