

Thumb Screw for ASFA L and S worm-drive clamps



Worm-drive clamps can be fitted relatively tightly, easily and quickly using this Thumb Screw, without the need for tools.

Once the clamp has been tightened, the thumb screw can be removed.

Ø Application	Part Number	Bandwidth mm	Box Quantity	Outer Box Quantity
All Ø available	02170461	9 / 12	100	1000

	TECHNICAL INFORMATION	
	MATERIAL	PLASTIC
	FINISH	AVAILABLE IN RED